

# **LCD Projector**

## **Owner's Instructions**

The color and the appearance may differ depending on the product, and the specifications are subject to change without prior notice to improve the performance.

# Table Of Contents

---

## MAJOR SAFETY PRECAUTIONS

Before You Start .....	1-1
Care and Maintenance .....	1-2
Safety Precautions .....	1-3

## INSTALLATION AND CONNECTION

Package Contents .....	2-1
Installing the Projector .....	2-2
Leveling with Adjustable Feet .....	2-3
Zoom and Focus Adjustment .....	2-4
Screen Size and Projection Distance .....	2-5
Adjusting the H-Keystone and V-Keystone .....	2-6
Lamp Replacement .....	2-7
Rear Side .....	2-8
Setting up the PC Environment .....	2-9
Supported Display Modes .....	2-10
Connecting the Power .....	2-11
Connecting with a PC .....	2-12
Connecting a PC using an HDMI/DVI cable .....	2-13
Connecting an External Monitor .....	2-14
Connecting an HDMI-Compatible Device .....	2-15
Connecting an AV device using a D-Sub cable .....	2-16
Connecting an AV device with component output .....	2-17
Connecting using a Video/S-Video cable .....	2-18
Connecting an External Speaker .....	2-19
Connecting to a Network .....	2-20
Kensington Lock .....	2-21

## USING

Product Features .....	3-1
Front, Upper .....	3-2
Remote Control .....	3-3
LED Indications .....	3-4
Using the Screen Adjustment Menu (OSD: On Screen Display) ....	3-5
Network Management .....	3-6

## TROUBLESHOOTING

Before Requesting Service .....	4-1
---------------------------------	-----

## MORE INFORMATION

Specifications .....	5-1
RS-232C Command Table .....	5-2
Contact SAMSUNG WORLDWIDE .....	5-3
Correct Disposal - Europe only .....	5-4



# 1 Major Safety Precautions

---

## 1-1 Before You Start

---

### Icons used in this manual

ICON	NAME	MEANING
	Caution	Indicates cases where the function may not work or the setting may be canceled.
	Note	Indicates a hint or tip to operate a function.

### Using this Manual

- Make yourself fully aware of the safety precautions before using this product.
- If a problem occurs, refer to the 'Troubleshooting' section.

### Copyright Notice

The contents of this manual are subject to change without prior notice for performance improvement.

**Copyright © 2009 Samsung Electronics Co., Ltd. All rights reserved.**

The copyright of this manual is reserved by Samsung Electronics, Co., Ltd.

The contents of this manual may not be partially or in whole reproduced, distributed or used in any form without the written permission of Samsung Electronics, Co., Ltd.


## 1-2 Care and Maintenance

---

### Cleaning the Surface and the Lens

Clean the projector using a soft dry cloth.

- Avoid cleaning the product with a flammable substance such as benzene or thinner.
- Avoid scratching the lense with your fingernails or a sharp object.  
This may result in scratches or damage to the product.
- Avoid cleaning the product with a wet cloth or by directly spraying water onto the product.  
If water enters the product, it may result in fire, electric shock, or a problem with the product.
- A white stain may appear on the surface of the projector if water gets on it.

 The appearance and the color may differ depending on models.



### Cleaning Inside the Projector



For cleaning the interior of the projector, contact a Service Center.

- Contact a Service Center if dust or other substances are inside the projector.



## 1-3 Safety Precautions

### Icons used for safety precautions

ICON	NAME	MEANING
	Warning	Failing to follow the precautions marked with this sign may result in a serious injury or even a fatality.
	Caution	Failing to follow the precautions marked with this sign may result in a personal injury or property damage.

### Meaning of Signs



Do not perform.



Do not disassemble.



Do not touch.



Must be followed.



The power plug must be unplugged from the wall outlet.



Must be grounded to prevent electric shock.

### Power Related

 The following images are for your reference and may differ depending on models and countries.




#### Warning




Plug the power plug in firmly.

- Otherwise, it may result in fire.



Avoid connecting multiple electric appliances to a single wall outlet.

- Otherwise, it may result in fire due to overheating of the wall outlet.



Avoid using a damaged power cord or plug or a loose power outlet.

- Otherwise, it may result in electric shock or fire.




Avoid bending or twisting the power cord excessively and avoid placing heavy objects on the cord.

- Otherwise, it may result in electric shock or fire due to a damaged power cord.



Avoid plugging in or unplugging the power supply with wet hands.

- Otherwise, it may result in electric shock.



To move the product, turn the power off and unplug the power cord and any other wires connected to the product.

- Otherwise, it may result in electric shock or fire due to the damaged power cord.



Make sure to connect the power cord to a grounded wall outlet (for insulation class 1 equipment only).

- Otherwise, it may result in electric shock or injury.



## Caution



When unplugging the power plug from the wall outlet, make sure to hold the power plug by the plug and not by the cord.

- Failing to do so may result in electric shock or fire.



Unplug the power plug before cleaning the product.

- There is a danger of electric shock or fire.




Connect the power plug to a wall outlet that can be easily reached.

- When a problem occurs with the product, you must unplug the power plug to cut the power off completely. You cannot cut the power off completely using only the power button on the product.



Do not turn the product on or off by plugging or unplugging the power plug. (Do not use the power plug as a power switch.)



Keep the power cord away from sources of heat.

## Installation Related



## Warning



Avoid installing the product in a location exposed to direct sunlight and installing the product near a heat source such as a fire or heater.

- This may shorten the product life cycle or cause fire.



Avoid installing the product in a badly-ventilated location such as inside a bookshelf or closet.

- Otherwise, it may result in fire due to internal overheating.




When installing the product in a cabinet or shelf, take care so that the front end of the product is completely supported by the cabinet or shelf.

- Failing to do so may result in the product falling and resulting in damage to the product or injury.
- Make sure to use a cabinet or shelf suitable to the size of the product.



When installing the product on a console or shelf, make sure that the front of the product does not protrude out of the console or shelf.

- Otherwise, this may cause the product to fall off and result in a malfunction or injury.



Keep the power cord away from heaters.

- The coating of the power cord may melt and cause electric shock or fire.



When thunder or lightning occurs, unplug the power cord.

- Failing to do so may result in electric shock or fire.



Do not install the product in a location exposed to dust, moisture (sauna), oil, smoke or water (rain drops) and do not install it in a vehicle.

- This may result in electric shock or fire.



Do not install the product in areas with heavy dust.

## Caution



Take care not to block the vent with a table cloth or curtain.

- Otherwise, it may result in fire due to internal overheating.



When putting the product down, place it gently.

- Failing to do so may result in a problem with the product or injury.



Do not let the product drop while moving it.

- This may result in a problem with the product or injury.



Do not install the product at a height where children may reach it.

- If a child touches the product, the product may fall and this may result in injury.

## Usage Related



Avoid inserting metal objects such as a chopsticks, coins or hairpins, or inflammable objects into the product (the vents, ports, etc).

- If water or an alien substance enters the product, turn the power off, unplug the power cord and contact a service center.
- Otherwise, it may result in a problem with the product, electric shock or fire.




Do not let children place objects such as toys or cookies on the product.

- If a child tries to reach for any of these objects, the product may fall and cause harm.



Do not disassemble, or attempt to fix or modify the product.

- When the product requires repairs, contact a Service Center.



Do not look directly at the light of the lamp nor project the picture into someone's eyes.

- This is dangerous, especially for children.



Avoid using or placing inflammable spray or objects near the product.

- This may result in an explosion or fire.



When you remove batteries from the remote, be careful that they are not swallowed by children. Keep batteries out of the reach of children.

- If swallowed, see a doctor immediately.



Avoid placing a liquid container such as a vase, flowerpot, beverage, cosmetics or drugs, or a metal object over the product.

- If water or an alien substance enters the product, turn the power off, unplug the power cord and contact a service center.
- Otherwise, it may result in a problem with the product, electric shock or fire.

## Caution



If the product generates a strange noise, a burning smell, or smoke, unplug the power plug immediately and contact a service center.

- Failing to do so may result in electric shock or fire.



If the power plug pin or jack is exposed to dust, water or alien substances, clean it thoroughly.

- There is a danger of electric shock or fire.



When cleaning the product, disconnect the power cord and clean the product with a soft dry cloth.

- Avoid using chemicals such as wax, benzene, alcohol, thinner, mosquito-repellent, fragrance, lubrication or cleansing agent when cleaning the product.

This may result in the exterior being deformed or the print being removed.



When not using the product for a long time, such as leaving your home, unplug the power cord from the wall outlet.

- Otherwise, it may cause dust accumulation and result in fire caused by overheating or a short circuit or result in an electric shock.



If the product is installed in a location where the operating conditions vary considerably, a serious quality problem may occur due to the surrounding environment. In this case, install the product only after consulting our Call Center.

- Places exposed to microscopic dust, chemicals, too high or low temperature, high humidity, such as airports or stations where the product is continuously used for a long time etc..



If you drop the product or the case is damaged, turn the power off and unplug the power cord. Contact a service center.

- Failing to do so may result in fire or electric shock.



Make sure to place your remote control on a table or desk.

- If you step on the remote control, you may fall and hurt yourself or the product may be damaged.



If water or a foreign substance enters the product, turn the product off, unplug the power cord from a wall outlet, and contact a Service Center.



Do not use the product while it indicates a malfunction, such as no sound or no picture.

- Turn the product off immediately, unplug the power cord from a wall outlet, and contact a Service Center.



When a gas leak occurs, do not touch the product or the power plug and ventilate immediately.

- A spark may result in an explosion or fire.
- During a thunder or lighting storm, do not touch the power cord or antenna cable



Do not touch the lens on the product.

- This may cause damage to the lens.



Do not touch any outer part of the product with tools such as a knife or a hammer.



To clean dirt or stains on the front projection lens, use spray or a wet cloth dampened with neutral detergent and water.



Ask a Service Center to clean the interior of the projector at least once per year.





To avoid burning yourself, do not touch the vents or lamp cover while operating or right after turning off the product.



Do not clean the product using water spray or a wet cloth. Avoid using any chemicals such as detergents, industrial or automotive polish, abrasive, wax, benzene, alcohol on any plastic part of the product such as projector case, since this may cause damage.



Do not open any cover on the product.

- This would prove hazardous because of high-voltage current inside the product.



Do not use any undesignated battery.



Be careful not to touch the ventilation hole while the projector is on as hot air comes out.



The ventilation hole is hot for some time though the projector is turned off. Keep your hands or body off the ventilation hole.



Do not place objects vulnerable to heat near the projector.




Be careful to keep your body away from the projector lamp. The lamp is hot.

(Children and those who have sensitive skin should be more careful.)








## 2 Installation and Connection

### 2-1 Package Contents

-  Unpack the product and check if all of the contents listed below have been included.
- Store the packaging box in case you need to move the product at a later date.



Projector

CONTENTS			
			
Quick Guide	Product Warranty (Not available in all locations)	User Manual	Power Cord
			
Remote Control / 1 Battery (CR 2025, Not available in all locations)	Cleaning Cloth	D-Sub Cable	

## 2-2 Installing the Projector

- Install the projector so that the beam from the projector is perpendicular to the screen.
  - Place the projector so that the lens aims at the center of the screen. If the screen is not vertical, the picture on the screen may not appear rectangular.
  - Do not install the screen in bright surroundings. If the surroundings are too bright, the picture on the screen will be washed out and not display clearly.
  - When using the projector in bright surroundings, use curtains to block the light.
  - You can install the projector in the following locations: Front-Floor / Front-Ceiling / Rear-Floor / Rear-Ceiling. To view the installation position settings, see below.

### To adjust picture when you install the projector behind the screen




Installing behind a semi-transparent screen.

When you install the projector behind a semi-transparent screen, you can use the menu to adjust the picture so that it displays correctly, depending on where you've located the projector, rear-floor (or low) or rear-ceiling.

1. For rear-floor, press :  
Menu > Setup > Install > Rear-Floor
2. For rear-ceiling, press :  
Menu > Setup > Install > Rear-Ceiling

### To adjust the picture when you install the projector in the front of the screen



Install the projector on the side where you are watching the screen.

When you install the projector in front of a screen, you can use the menu to adjust the picture so that it displays correctly, depending on where you've located the projector, front-floor (or low) or front-ceiling.

1. For front-floor, press :  
Menu > Setup > Install > Front-Floor
2. For front-ceiling, press :  
Menu > Setup > Install > Front-Ceiling

## 2-3 Leveling with Adjustable Feet

---



To level the projector, turn the Adjustable Feet of the projector.




The projector can be adjusted to a height of up to 30 mm (about 12 °) from the reference point.

Depending on the position of the projector, Keystone distortion of the image may appear.

If <Auto Keystone> is set to <On>, any keystone will be automatically adjusted. If fine tuning is required after auto-adjustment, tune using the <Keystone>.

## 2-4 Zoom and Focus Adjustment


---



- ① Zoom Knob : You can adjust the size of the image within the zoom range by manipulating the Zoom Knob.
- ② Focus Ring : Focus the picture on the screen using the Focus Ring.

- 🔧 The size of your screen determines the distance you set your projector from the screen.  
If you do not install your projector at the projection distance specified in the Screen Size and Projection Distance table, you will not be able to adjust the focus correctly.

## 2-5 Screen Size and Projection Distance



**A. Screen / Z. Throw Distance / Y'. Distance from Lens Center to Image Bottom**

Install the projector on a flat, even surface and level the projector using the adjustable feet to obtain optimal picture quality. If images are not clear, adjust them using the Zoom Knob or Focus Ring, or move the projector forward and backward.

SCREEN SIZE						THROW DISTANCE				OFFSET	
M (DIAGONAL)		X (HORIZONTAL)		Y (VERTICAL)		Z (TELE)		Z (WIDE)		Y'	
INCHES	CM	INCHES	CM	INCHES	CM	INCHES	CM	INCHES	CM	INCHES	CM
40	101.6	32	81.3	24	61.0	54.2	137.6	44.9	114.0	4.0	10.2
50	127.0	40	101.6	30	76.2	68.0	172.7	56.4	143.3	5.0	12.7
60	152.4	48	121.9	36	91.4	81.8	207.8	68.0	172.6	6.0	15.2
70	177.8	56	142.2	42	106.7	95.7	243.0	79.5	202.0	7.0	17.8
80	203.2	64	162.6	48	121.9	109.5	278.1	91.1	231.3	8.0	20.3
90	228.6	72	182.9	54	137.2	123.4	313.3	102.6	260.6	9.0	22.9
100	254.0	80	203.2	60	152.4	137.2	348.4	114.1	289.9	10.0	25.4
110	279.4	88	223.5	66	167.6	151.0	383.5	125.7	319.2	11.0	27.9
120	304.8	96	243.8	72	182.9	164.8	418.7	137.2	348.5	12.0	30.5
130	330.2	104	264.2	78	198.1	178.7	453.8	148.7	377.8	13.0	33.0
140	355.6	112	284.5	84	213.4	192.5	488.9	160.3	407.1	14.0	35.6
150	381.0	120	304.8	90	228.6	206.3	524.1	171.8	436.4	15.0	38.1
160	406.4	128	325.1	96	243.8	220.2	559.2	183.4	465.7	16.0	40.6
170	431.8	136	345.4	102	259.1	234.0	594.4	194.9	495.0	17.0	43.2
180	457.2	144	365.8	108	274.3	247.8	629.5	206.4	524.3	18.0	45.7
190	482.6	152	386.1	114	289.6	261.7	664.6	218.0	553.6	19.0	48.3
200	508.0	160	406.4	120	304.8	275.5	699.8	229.5	582.9	20.0	50.8
210	533.4	168	426.7	126	320.0	289.3	734.9	241.0	612.2	21.0	53.3
220	558.8	176	447.0	132	335.3	303.2	770.1	252.6	641.5	22.0	55.9
230	584.2	184	467.4	138	350.5	317.0	805.2	264.1	670.8	23.0	58.4
240	609.6	192	487.7	144	365.8	330.8	840.3	275.6	700.1	24.0	61.0
250	635.0	200	508.0	150	381.0	344.7	875.5	287.2	729.4	25.0	63.5
260	660.4	208	528.3	156	396.2	358.5	910.6	298.7	758.7	26.0	66.0

SCREEN SIZE						THROW DISTANCE				OFFSET	
M (DIAGONAL)		X (HORIZONTAL)		Y (VERTICAL)		Z (TELE)		Z (WIDE)		Y'	
INCHES	CM	INCHES	CM	INCHES	CM	INCHES	CM	INCHES	CM	INCHES	CM
270	685.8	216	548.6	162	411.5	372.3	945.7	310.2	788.0	27.0	68.6
280	711.2	224	569.0	168	426.7	386.2	980.9	321.8	817.3	28.0	71.1
290	736.6	232	589.3	174	442.0	400.0	1016.0	333.3	846.6	29.0	73.7
300	762.0	240	609.6	180	457.2	413.9	1051.2	344.9	875.9	30.0	76.2

 This projector is designed to show images optimally on a 80 ~ 120 inches sized screen.


## 2-6 Adjusting the H-Keystone and V-Keystone

If you install the projector below the center line of the screen (near the ceiling or on the floor, for example), the angle at which the projector is set to the screen causes the image it projects to be distorted.


<H-Keystone> and <V-Keystone> adjust for the angle at which the projector is set to the screen so that the shape of the image displayed by the projector appears rectangular.

To set the the <H-Keystone> and <V-Keystone>, follow these steps:

1. Turn on the projector, and then press the Menu button on the projector or the remote control.
2. Select Setup, and then press Enter.
3. Make sure that Install at the top of the menu is set to the correct installation position: <Front-Floor>, <Front-Ceiling>, <Rear-Floor>, or <Rear-Ceiling>.
4. Select <Keystone>, and then press Enter.
5. Select <V-Keystone>, and then press Enter.
6. Press the Left or Right arrow key to set <V-Keystone> to 0.
7. Press the Up or Down arrow key to select <H-Keystone>. Set <H-Keystone> to 0.
8. Return to the <Setup> Menu, select Test Pattern, and then press Enter.
9. Select Cross Hatch, and then press Enter.
10. Attach a string to the screen and make sure it hangs straight down.
11. Adjust the location of the projector until the string (1) and the center vertical line(2) in the Cross Hatch image are parallel.






**Screen : (1) A virtual vertical line made on the screen using a piece of thread, etc.**



**Crosshatch Test Pattern : (2) A vertical line in the middle of the Test Pattern**




12. Adjust the projector's angle so that a corner of the projected picture (which is nearest to the projector) meets that of the screen. In the illustration below, this corner is labeled D.





**A : Projector / B : Screen / C : Projected image / D : A corner of the picture nearest to the projector**

13. Adjust the projector's angle until the projected image covers the entire screen area. The image can overlap.

-  The projected image may not cover the entire screen depending on the projector's installation height. In this case, adjust the projector's angle so that the entire screen is covered.


14. Press the V.KEY-STONE button on the remote control. The <V-Keystone> menu appears. Adjust <V-Keystone> using the + or - button on the remote control.




**A : Projector / B : Screen / C : Projected image**

 Keep adjusting until the vertical line on the <Test Pattern> becomes parallel with the outer vertical edge of the screen.

15. Press the ▲ or ▼ button to select <H-Keystone>. Adjust <H-Keystone> using the + or - button on the remote control.







**A : Projector / B : Screen / C : Projected image**

- Keep adjusting until the horizontal line on the <Test Pattern> becomes parallel with the outer horizontal edge of the screen.

16. Adjust the screen size using the zoom knob.

17. If any part of the projected image is larger than the screen, adjust the size of the projected image using the <Custom> option in the <Size> menu. For instructions on using the <Custom> option, see below.



**A : Projector / B : Screen / C : Projected image**

To use the <Custom>option, follow these steps :

- 1. Press the MENU button.
- 2. Select <Picture> to move on to the <Size> menu.
- 3. Select the <Custom> option and then select an area to adjust.
- 4. Adjust the screen size using the ▲ or ▼ button.

- Keystone, which is a feature to calibrate an image skew, may degrade the brightness and resolution once it is activated.

### Cautions on Lamp Replacement

- The projector lamp is an expendable item. For best operating performance, replace the lamp according to the usage time. You can view the lamp usage time in the Information Display (INFO button).
- Use the recommended lamp when replacing. Replace the lamp with the one specified below.
  - Lamp Model Name : 220W UHP E19.5
  - Lamp Manufacturer : Philips
  - For inquiries on lamp purchase, please see 'Contact SAMSUNG WORLDWIDE' in section 5-4.
- Check that the power cord is unplugged before replacing the lamp.
- Because the lamp is a high temperature and high voltage product, wait at least one hour from the time you disconnect the power cord before replacing the lamp.
- The lamp is located on the left side of the projector (when looking from the front).
- Do not leave the old lamp near inflammables or in reach of children. There is a danger of fire, burns or injury.
- Remove dirt or foreign material around or inside the lamp unit using a proper vacuum device.
- When handling the lamp, avoid touching any part of it except for the handles. If you handle the lamp incorrectly, you can shorten the lamp's lifetime and affect picture quality.
- When you turn the projector over to change the lamp, put the projector on a soft cloth on a flat surface.
- The projector has been designed so that the projector does not work if the lamp cover is not completely assembled after a lamp replacement. If the projector does not work properly, please check the operating status of the indicator LED.

**Lamp contains Mercury. Dispose According to Local, State or Federal Laws.**

### Lamp Replacement Procedure

-  Because the lamp is a high temperature and high voltage product, wait at least one hour from the time that the power cord is disconnected before replacing it.

The lamp is located on the left side of the projector (when looking from the front).


1. Remove the screw shown in the figure below and then open the cover.



2. Remove the two (2) screws shown in the figure below.



3. Hold and pull the lamp handle out of the projector, as shown in the figure below.



 Assemble a new lamp in the reverse order of disassembly.

## Replacing and Cleaning the Filter

Precautions when replacing the projector filter:

- The filter is located at the bottom of the projector.
- Turn off the power of the projector, and then disconnect the power cord after the projector has cooled sufficiently. Otherwise, its parts may be damaged due to internal heat.
- When you replace the filter, you may release some dust.
- For inquiries on filter purchase, please see 'Contact SAMSUNG WORLDWIDE' in Chapter 5.

The sequence for replacing or cleaning the filter of the projector.

1. Turn off the power of the projector, and then disconnect the power cord after the projector has cooled sufficiently.



2. Turn the projector over so that its bottom points upward, and then push and remove the filter cover in the direction of the arrow in the illustration below.

\* When placing the projector with the bottom facing up, make sure to place a soft cloth under the projector to prevent scratches.



3. Replace or clean the filter.



- When cleaning the filter, use a small vacuum cleaner designed for computers and small electronics products, or wash it under

running water.


- After washing the filter under running water, make sure to dry it completely. The moisture may cause the filter to corrode.
- If dust cannot be separated from the filter or the filter is torn, it must be replaced.
- Make sure to select the Reset Filter Time option after replacing or cleaning the filter of the projector

## Ventilation openings

The location of the ventilation openings:

- The ventilation openings are located on the right and left sides and at the bottom of the projector.






- |                                   |                           |
|-----------------------------------|---------------------------|
| 1. PC IN port                     | 8. AUDIO OUT port         |
| 2. PC/DVI AUDIO IN port           | 9. [AV IN] R-AUDIO-L port |
| 3. HDMI/DVI IN port               | 10. [AV IN] VIDEO port    |
| 4. LAN port                       | 11. [AV IN] S-VIDEO port  |
| 5. Remote Control Signal Receiver | 12. Kensington Lock       |
| 6. RS-232C port                   | 13. Power port            |
| 7. PC OUT port                    |                           |

## 2-9 Setting up the PC Environment

Check the following items before connecting your PC to your projector.


1. Click the right mouse button on the Windows desktop, and then click [Properties].  
The <Display Properties> dialog appears.



2. Click the [Settings] tab, and then set the <Screen resolution>. The optimal resolution for the projector is 1024 x 768. For other resolutions supported by the projector, see the PC Timing Display Mode table in section 2-10.


 You do not have to change the <Color quality> setup.

3. Press the [Advanced] button. Another property window appears.




4. Click the [Monitor] tab and set the <Screen refresh rate>. For the refresh rate that matches the resolution you've chosen, see the refresh rate (60 Hz, 70 Hz, etc.) next to your selected resolution in the PC Timing Display Mode table in section 2-10.

 Setting the refresh rate sets both the vertical and horizontal frequencies.





5. Click the [OK] button to close the window, and then click the [OK] button on the <Display Properties> window to close that window. The computer may restart automatically.
6. Shut down the PC and connect it to the projector.

 The setup process might vary depending on your type of computer or version of Windows.  
(For example, [Properties] appears instead of [Properties (R)] as shown in 1.)  
This projector supports 32 bit color quality (per pixel) when it is used as a PC monitor.  
Projected images may differ from the images on your monitor depending on the monitor manufacturer or Windows version.  
When connecting the projector to a PC, make sure that the PC setup complies with the display settings supported by this projector. If it does not, you may have signal problems.

## 2-10 Supported Display Modes

### PC Timing (D-Sub/HDMI)

FORMAT	RESOLUTION		HORIZONTAL FREQUENCY (KHZ)	VERTICAL FREQUENCY (HZ)	PIXEL FREQUENCY (MHZ)
IBM	640 x 350	70Hz	31.469	70.086	25.175
IBM	640 x 480	60Hz	31.469	59.940	25.175
IBM	720 x 400	70Hz	31.469	70.087	28.322
VESA	640 x 480	60Hz	31.469	59.940	25.175
MAC	640 x 480	67Hz	35.000	66.667	30.240
VESA	640 x 480	70Hz	35.000	70.000	28.560
VESA	640 x 480	72Hz	37.861	72.809	31.500
VESA	640 x 480	75Hz	37.500	75.000	31.500
VESA	720 x 576	60Hz	35.910	59.950	32.750
VESA	800 x 600	56Hz	35.156	56.250	36.000
VESA	800 x 600	60Hz	37.879	60.317	40.000
VESA	800 x 600	70Hz	43.750	70.000	45.500
VESA	800 x 600	72Hz	48.077	72.188	50.000
VESA	800 x 600	75Hz	46.875	75.000	49.500
MAC	832 x 624	75Hz	49.726	74.551	57.284
VESA	1024 x 768	60Hz	48.363	60.004	65.000
VESA	1024 x 768	70Hz	56.476	70.069	75.000
VESA	1024 x 768	72Hz	57.672	72.000	78.434
VESA	1024 x 768	75Hz	60.023	75.029	78.750
VESA	1152 x 864	60Hz	53.783	59.959	81.750
VESA	1152 x 864	70Hz	63.000	70.000	96.768
VESA	1152 x 864	72Hz	64.872	72.000	99.643
VESA	1152 x 864	75Hz	67.500	75.000	108.000
VESA	1280 x 720	60Hz	44.772	59.855	74.500
VESA	1280 x 720	70Hz	52.500	70.000	89.040
VESA	1280 x 720	72Hz	54.072	72.000	91.706
VESA	1280 x 720	75Hz	56.456	74.777	95.750
VESA	1280 x 768	60Hz	47.776	59.870	79.500
VESA	1280 x 768	75Hz	60.289	74.893	102.250
VESA	1280 x 800	60Hz	49.702	59.810	83.500
VESA	1280 x 800	75Hz	62.795	74.934	106.500
VESA	1280 x 960	60Hz	60.000	60.000	108.000
VESA	1280 x 960	70Hz	69.930	70.000	120.839

FORMAT	RESOLUTION		HORIZONTAL FREQUENCY (KHZ)	VERTICAL FREQUENCY (HZ)	PIXEL FREQUENCY (MHZ)
VESA	1280 x 960	72Hz	72.072	72.000	124.540
VESA	1280 x 960	75Hz	75.231	74.857	130.000
VESA	1280 x 1024	60Hz	63.981	60.020	108.000
VESA	1280 x 1024	70Hz	74.620	70.000	128.943
VESA	1280 x 1024	72Hz	76.824	72.000	132.752
VESA	1280 x 1024	75Hz	79.976	75.025	135.000
VESA	1400 x 1050	60Hz	65.317	59.978	121.750
VESA	1440 x 900	60Hz	55.935	59.887	106.500
VESA	1440 x 900	75Hz	70.635	74.984	136.750
VESA	1600 x 1200	60Hz	75.000	60.000	162.000

 For the resolutions presented above, if a signal with a resolution lower or higher than 1024x768 is input, it is converted to 1024x768 by the Scaler chip inside the projector.

When the real resolution (1024x768) of the projector and the PC output resolution are the same, the screen quality is optimal.

## AV Timing (D-Sub)

FORMAT	RESOLUTION		SCAN
BT.601 SMPTE 267M	480i	59.94Hz	Interlaced
BT.1358 SMPTE 293M	480p	59.94Hz	Progressive
BT.601	576i	50Hz	Interlaced
BT.1358	576p	50Hz	Progressive
SMPTE 296M	720p	59.94Hz/60Hz	Progressive
	720p	50Hz	Progressive
BT.709 SMPTE 274M	1080i	59.94Hz/60Hz	Interlaced
	1080i	50Hz	Interlaced

## AV Timing (HDMI)

FORMAT		RESOLUTION	SCAN	HORIZONTAL FREQUENCY (KHZ)	VERTICAL FREQUENCY (HZ)	PIXEL FREQUENCY (MHZ)
EIA-861	Format1	640 x 480	Progressive	59.940	31.469	25.175
EIA-861	Format1	640 x 480	Progressive	60.000	31.500	25.200
EIA-861	Format2,3	720 x 480	Progressive	59.940	31.469	27.000
EIA-861	Format2,3	720 x 480	Progressive	60.000	31.500	27.027
EIA-861	Format4	1280 x 720	Progressive	59.939	44.955	74.175
EIA-861	Format4	1280 x 720	Progressive	60.000	45.000	74.250


FORMAT		RESOLUTION	SCAN	HORIZONTAL FREQUENCY (KHZ)	VERTICAL FREQUENCY (HZ)	PIXEL FREQUENCY (MHZ)
EIA-861	Format5	1920 x 1080	Interlaced	59.939	33.716	74.175
EIA-861	Format5	1920 x 1080	Interlaced	60.000	33.750	74.250
EIA-861	Format17,18	720 x 576	Progressive	50.000	31.250	27.000
EIA-861	Format19	1280 x 720	Progressive	50.000	37.500	74.250
EIA-861	Format20	1920 x 1080	Interlaced	50.000	28.125	74.250

## AV Timing (VIDEO/S-VIDEO)

NTSC, NTSC 4.43, PAL, PAL60, PAL-N, PAL-M, SECAM


## 2-11 Connecting the Power

---



1. Plug the power cord into the power terminal on the rear side of the projector.

## 2-12 Connecting with a PC




1. Connect the [PC IN] port on the rear side of the projector to the monitor output port of the PC using a PC video cable.
2. Plug in the power cords of the projector and the PC.
3. Connect the [PC/DVI AUDIO IN] input port of the projector to the speaker output ports of the PC using an audio cable.

 This product supports Plug and Play. If you use Windows XP, you do not need to set up the driver on your PC.

### Using the Projector

1. Turn on the projector, and then press the [SOURCE] button to select <PC>. If the <PC> Mode is not available, make sure the PC video cable is properly connected.
2. Turn on the PC, and then set the PC Environment if necessary.
3. Adjust the screen. (<Auto Adjustment>)


## 2-13 Connecting a PC using an HDMI/DVI cable



Make sure that your PC and projector are turned off.

1. Connect the [HDMI/DVI IN] terminal of the projector to the HDMI or DVI terminal of your PC using a HDMI/HDMI or HDMI/DVI cable (Not supplied).
  - If you are connecting to the HDMI terminal of your PC, use an HDMI/HDMI cable (Not supplied).
  - For the supported resolutions and refresh rates, see PC Timing (D-Sub/HDMI) in Section 2-10.
2. If you connected using a HDMI/DVI cable, connect the [PC/DVI AUDIO IN] terminal of the projector to the Audio out terminal of your PC using an audio cable (Not supplied).
  - If you connected with a HDMI/HDMI cable, you do not need an audio cable.

## 2-14 Connecting an External Monitor




You can view an image on both your projector and a separate monitor at the same time.

Make sure that your PC and projector are turned off.

1. Connect the [PC IN] terminal at the back of the projector to the D-Sub terminal of your PC using a D-Sub cable.
2. Connect the [PC OUT] terminal of the projector to the D-Sub terminal of a monitor using a D-Sub cable.
  - When connecting a monitor using the [PC OUT] function, make sure to connect your PC to the [PC IN] terminal.
  - The video on the monitor connected to the [PC OUT] terminal will be normal even if you see a blank screen on your projector.
  - The [PC OUT] function will not operate in standby mode.




## 2-15 Connecting an HDMI-Compatible Device



Make sure that the AV device and your projector are turned off.

1. Connect the [HDMI/DVI IN] terminal at the back of the projector to the HDMI or HDMI/DVI output terminal of the digital output device using an HDMI/DVI or HDMI/HDMI cable.
  - If you are connecting to the HDMI output terminal on the digital output device, use an HDMI/HDMI cable.
  - For supported input signal formats, resolutions, and frequencies, see AV Timing(HDMI) in Section 2-10.
2. If you connected using a HDMI/DVI cable, connect the [PC/DVI AUDIO IN] terminal on the projector to the Audio out terminal on your digital output device using an audio cable (Not supplied).
  - If you connected with a HDMI/HDMI cable, you do not need an audio cable.


## 2-16 Connecting an AV device using a D-Sub cable



Make sure that the AV device and your projector are turned off.

1. Connect the [PC IN] terminal at the back of the projector to the D-Sub terminal of your AV device using a D-Sub cable.  
- For supported input signal formats, resolutions, and frequencies, see AV Timing (D-Sub) in Section 2-10.
2. Connect the [PC/DVI AUDIO IN] terminal at the back of the projector to the Audio out terminal of your AV device using an audio cable (Not supplied).


## 2-17 Connecting an AV device with component output



Make sure that the AV device and your projector are turned off.

1. Connect the [PC IN] terminal on the back of the projector to the Component terminal on your AV device using a D-Sub to Component cable (Not supplied). This cable has a D-Sub connector on one end and three RCA jacks on the other.  
- For supported input signal formats, resolutions, and frequencies, see AV Timing (D-Sub) in Section 2-10.
2. Connect the [PC/DVI AUDIO IN] terminal on the back of the projector and the Audio out terminal on your AV device using an audio cable (Not supplied).

## 2-18 Connecting using a Video/S-Video cable




Make sure that the AV device and your projector are turned off.

1. Connect the [VIDEO] or [S-VIDEO] terminal and the AV device using a Video cable (Not supplied) or S-Video cable (Not supplied).
  - For supported input signal formats, see AV Timing (VIDEO/S-VIDEO) in section 2-10.
2. Connect the [AV IN R-AUDIO-L] terminal on the back of the projector and the Audio out terminal on your AV device using an audio cable (Not supplied).

## 2-19 Connecting an External Speaker

---



You can hear sound through an external speaker instead of the internal speakers embedded in the projector.


1. Obtain an audio cable (Not supplied) suitable for your external speaker.
2. Connect the [AUDIO OUT] terminal of the projector to the external speaker using an audio cable.
  - When using an external speaker, the internal speaker does not operate but you can adjust the volume of the external speaker using the Volume button of the projector (or remote control).
  - The [AUDIO OUT] terminal can output all audio signals.

## 2-20 Connecting to a Network

 This product can use network function. Refer to the following Network connection method.

### 2-20-1. Connecting to a Dynamic IP (DHCP) Network

You can attach the projector to your network by connecting it to the network through a modem that uses DHCP (Dynamic Host Configuration Protocol). When you use a DHCP modem, the modem automatically provides the IP address, subnet mask, gateway, and DNS server values that the projector needs to access the network.



To connect to a DHCP network, follow these steps :


1. Connect the modem cable between the modem port on the wall and the external modem.
2. Connect a LAN cable between the external modem and the wired or wireless IP router.
3. Connect a LAN cable between the [LAN] port on the back of the projector and the wired or wireless IP router.
4. Turn on the projector, and then press the Menu button.
5. Select <Setup> → <Network> → <IP Setting> → <IP Setting> → <Automatic>.
6. The projector automatically acquires the IP address, Subnet mask and Gateway.

 To use the network function, <Network> must be set to <On>.

 If the IP address allotment from the DHCP server fails, turn off the external modem for more than 10 seconds, restart the modem, and then retry the connection.


 For instructions on the setup and connection of the external modem and Router, refer to the user manual for each product.

 You can connect the LAN cable from the modem directly to the projector, You do not need a router.

 You can not use a manual connection-type ADSL modem because it is not a DHCP-type device. Make sure to use an automatic connection DHCP ADSL modem.

## 2-20-2. Connecting to a Static IP Network

You can attach the projector to a network that uses a Static IP address, which corresponds to using a dedicated lease line. If your network uses Static IP addresses, you must get the IP address, subnet mask, gateway, and DNS server values from your Internet Service Provider (ISP), turn on the Network function in the projector's Menu, and then enter the values into the Network function manually.




To connect to a Static IP address network, follow these steps :

1. Connect a LAN cable between the LAN port on the wall and a wired or wireless IP router.
2. Connect a LAN cable between the [LAN] port on the back of the projector and the wired or wireless IP router.
3. Turn on the projector, and then press the Menu button.
4. Select <Setup> → <Network> → <IP Setting> → <IP Setting> → <Manual>.

 To use the network function, <Network> must be set to <On>.

5. Press the Enter button. Use the ◀/▶ buttons to navigate between each IP Address entry field and the ▲/▼ buttons to enter values.
6. When done entering all the values for IP Address, press Enter button and then repeat the steps for Subnet mask and Gateway.
7. When done entering all the values, press the Menu button or Return button to exit.

 If you use a static IP, your ISP will inform you of your IP address, subnet mask, gateway and DNS values. These values must be entered to complete your network setup. If you do not know your static IP address, consult your network administrator.

 For instructions on the setup and connection of the router, refer to the router's user manual.


 You can connect the LAN cable directly to the projector without using a router.

 If you use an IP Router which supports the DHCP function, you can set the router to either DHCP or static IP.

 For instructions on the use of a static IP, consult your Internet service provider.

## 2-21 Kensington Lock

A Kensington Lock (not supplied) is an anti-theft device that lets users lock the product so that they can safely use it in public locations. Because the shape and usage of the lock may differ depending on the model and the manufacturer, see the User Manual supplied with the locking device for more information.



### Locking the product

1. Loop the Kensington lock cable around an immovable part of desk or heavy object as directed in the Kensington lock user manual.
2. Insert the locking part of the locking device into the Kensington lock hole in the projector.
3. Insert the Kensington lock key into the locking mechanism and turn it in the locking direction.

 You can purchase the locking device from an electronics store or an online shop.



## 3 Using

---







### 3-1 Product Features

---


1. An optical engine adopting new LCD technology
  - 1024 x 768 panel has been adapted.
  - Utilizes a 3P-LCD panel.
  - SP-L301 : Provides a bright screen of 3000 lumen.  
SP-L331 : Provides a bright screen of 3300 lumen.  
SP-L351 : Provides a bright screen of 3500 lumen.
  - Compact size, lightweight, and portable.
2. Minimized fan noise
  - Minimizes fan noise through optimized internal air flow and the fan installation structure.
3. Multiple input terminals
  - Increases the connectivity to peripheral devices such as D-Sub 15P (supporting DTV signal), S-Video, Video, HDMI, etc.
4. Audio Output
  - Includes stereo speakers on the right and left and a 5-band equalizer.
5. User adjustments
  - Allows adjustment of each input port.
  - Has a reference pattern you can use for positioning and adjustment.
6. Convenient Network Function
  - The projector can be monitored and controlled from a PC using the network function.

## 3-2 Front, Upper



NAME	DESCRIPTION
<b>1. Indicators</b>	<ul style="list-style-type: none"> <li>- STAND BY (Blue LED)</li> <li>- LAMP (Blue LED)</li> <li>- TEMP (Red LED)</li> </ul> <p> Refer to the LED Indications.</p>
<b>2. Move <math>\Delta V &lt;&gt;</math> / Select  / Volume  button</b>	<p><math>\Delta V &lt;&gt;</math> / : Use to move to or select an item within a menu.</p> <p>: Use to adjust the volume.</p>
<b>3. MENU button</b>	Use to display the Menu Screen.
<b>4. SOURCE button</b>	Use to select the external device signal.
<b>5.  Button</b>	Use to turn the projector on or off.
<b>6. Lens</b>	Use for Focus Adjustment.
<b>7. Remote Control Signal Receiver</b>	-
<b>8. Zoom Knob</b>	Use to enlarge or reduce image size.
<b>9. Focus Ring</b>	Use for Focus Adjustment.
<b>10. Lens cover</b>	-

### 3-3 Remote Control



1. **POWER ( )** Button  
Use this button for turning the product on and off.
2. **AUTO** Button  
Adjusts the Picture automatically. (Available in < PC> Mode Only)
3. **MENU ( )** Button  
Used to display the Menu Screen.
4. **Move ( )/ ( )** Buttons  
Used to display the Menu Screen.
5. **V. KEYSTONE ( + - )** Button  
Use this when the screen is displayed in a trapezoid shape.
6. **INSTALL** Button  
Used to flip or reverse the projected image.
7. **BLANK** Button  
This is used to turn off the screen and sound temporarily. The video and audio will come back on when any button other than the [POWER] button is pressed.
8. **P.SIZE** Button  
Used to adjust the size of picture screen.
9. **QUICK** Button  
This is used to quickly return to the last menu used.
10. **MUTE ( )** Button  
Press to mute the sound temporarily. Press the MUTE button again or the VOL button ( ^ v ) when the sound is muted to hear sound again.
11. **RETURN ( )** Button  
Returns to the previous menu.
12. **EXIT ( )** Button  
Used to make the Menu Screen disappear.
13. **VOL ( ^ v )** Button  
Used to control the volume.
14. **INFO** Button  
Used to check source signals, picture setup, PC screen adjustment and lamp lifespan.
15. **SOURCE** Button  
Used to check or select the connection status of external devices.
16. **P.MODE** Button  
Used to select Picture Mode.
17. **STILL** Button  
Used to see still images.

- 📌 Make sure to place your remote control on a table or desk. If you step on the remote control, you may fall and hurt yourself or damage the remote.
- 📌 You can use the remote control up to a distance of about 23 feet (7 m) from the product.


### LED Indications

●:Light is On ●:Light is Blinking ○:Light is Off

STAND BY	LAMP	TEMP	STATUS
●	○	○	If you press the [POWER] button on the remote control or projector, the screen appears within 30 seconds.
●	●	○	The projector is operating normally.
●	●	○	The projector is preparing an operation after the [POWER] button on the projector or the remote control has been pressed.
○	●	○	The [POWER] button has been pressed to turn off the projector, and the cooling system is in operation to cool off the inside of the projector. (Operates for about 3 seconds.)
●	○	●	The cooling fan inside the projector is not operating normally. Refer to Action 1 in Clearing Indicator Problems below.
○	●	●	The lamp cover protecting the lamp unit is not closed properly. Refer to Action 2 in Clearing Indicator Problems below.
●	●	●	The lens cover has not opened completely. Refer to Action 3 in Clearing Indicator Problems below.
●	●	●	The projector has changed to Cooling mode because its internal temperature has increased beyond the maintenance limit. Refer to Action 4 in Clearing Indicator Problems below.
○	○	●	The projector has turned itself off automatically because its internal temperature has increased beyond the maintenance limit. Refer to Action 5 in Clearing Indicator Problems below.
●	●	●	A problem has occurred with the operation of the lamp. Refer to Action 6 below.
●	●	●	The lifetime of the lamp has expired. Refer to Action 7.
●	●	●	The power for the product is not operating normally. Contact a service center.





## Clearing Indicator Problems


CLASSIFICATION	STATE	MEASURES
Action 1	The cooling fan system is not operating normally.	If the symptom remains even after disconnecting and then reconnecting the power cord and turning the projector on again, contact your product provider or our service center.
Action 2	The lamp cover protecting the lamp unit is not properly closed or the sensor system is not operating normally.	Check if the screws on the side of the projector are securely tightened. If they are and the indicators are still lit, contact your product distributor or a service center.
Action 3	The lens cover has not opened completely.	Open the lens cover completely. If the lens cover does not open completely when the projector is operating, both the video and audio turn off automatically. If this status persists for ten minutes, the projector turns off automatically.
Action 4	The projector has changed to Cooling mode because the internal temperature of the projector has increased beyond the maintenance limit.	If the internal temperature of the projector has increased beyond the maintenance limit, the projector changes to Cooling mode before turning off automatically. In Cooling mode, the fan speed is increased and the projector's lamp is changed to <ECO> mode. Check whether the ventilation hole of the projector is blocked. Check the air filter and clean if blocked. Check whether the surrounding temperature of the projector is higher than the standard temperature range of the projector. Cool the projector sufficiently and operate it again.
Action 5	The internal temperature of the projector has risen higher than the limit, and the projector has turned off automatically.	Check whether the ventilation hole of the projector is blocked. Check the air filter and clean if blocked. Check whether the surrounding temperature of the projector is higher than the standard temperature range of the projector. Cool the projector sufficiently and operate it again. If the same problem occurs continually, contact your product distributor or service center.
Action 6	The lamp has malfunctioned after power turns off abnormally or after powering on right after turning off the projector.	Turn the power off, wait for a sufficient amount of cooling time and then turn the power on to operate. If the same problem occurs continually, contact your product distributor or service center.
Action 7	When the screen becomes darker	Check the lamp usage time on the Information Display screen. If you need to replace the lamp, contact your product distributor or service center.

 This Projector uses a cooling fan system to keep the unit from overheating. Operation of the cooling fan may cause noise, This does not affect product performance and is part of normal operation.

### 3-5 Using the Screen Adjustment Menu (OSD: On Screen Display)

#### The Screen Adjustment Menu (OSD: On Screen Display) Structure

MENU	SUB-MENU				
 Input	Source List	Edit Name			
	Mode	Size	Position	Digital NR	Black Level
 Picture	Overscan	Film Mode	PC	Zoom	
	Install	Lamp Mode	Auto Keystone	Keystone	Background
 Setup	Test Pattern	Video Type	Caption	Network	Reset
	Language	Menu Option	Sound	Filter Check Time	Auto Power On
 Option	Sleep Timer	Information			


 To access the Menu, press the Menu button on the product or on the remote. To move in the menu, press the arrow buttons. Menu selections with an arrow on the far right have sub-menus. Press the right arrow button to access the sub-menu. Directions for navigating and selecting items in a menu are at the bottom of each menu screen.








#### 3-5-1. Input











MENU	DESCRIPTION
Source List	You can select a device connected to the projector to display. <ul style="list-style-type: none"><li>&lt;PC&gt;-&lt;AV&gt;-&lt;S-Video&gt;-&lt;HDMI&gt;</li></ul>
Edit Name	You can edit the names of devices connected to the projector. <ul style="list-style-type: none"><li>&lt;VCR&gt;-&lt;DVD&gt;-&lt;Cable STB&gt;-&lt;Satellite STB&gt;-&lt;PVR STB&gt;-&lt;AV Receiver&gt;-&lt;Game&gt;-&lt;Camcorder&gt;-&lt;PC&gt;-&lt;DVI Devices&gt;-&lt;TV&gt;-&lt;IPTV&gt;-&lt;Blu-ray&gt;-&lt;HD DVD&gt;-&lt;DMA&gt;</li></ul>

#### 3-5-2. Picture







MENU	DESCRIPTION
Mode	<p>Select a screen state which is customized to your projector or change the screen mode as required.</p> <ul style="list-style-type: none"> <li>&lt;Mode&gt; <ul style="list-style-type: none"> <li>&lt;Standard&gt; : This picture mode is the most general mode and works well in most situations.</li> <li>&lt;Presentation&gt; : This mode is suitable for presentations.</li> <li>&lt;Text&gt; : This mode is suitable for text work.</li> <li>&lt;Movie&gt; : This mode is suitable for viewing a movie.</li> <li>&lt;Game&gt; : This picture mode is optimized for playing games.</li> </ul> </li> <li> The text in a still picture appears unnatural.</li> <li>&lt;User&gt; : This mode is a customized mode created using the &lt;Mode&gt;→&lt;Save&gt; function.</li> <li> Presentation and Text modes are only enabled if the input signal is a PC Timing (D-Sub/HDMI) signal.</li> <li> Each mode has separate controls for &lt;Contrast&gt;, &lt;Brightness&gt;, &lt;Sharpness&gt;, &lt;Color&gt;, etc. When you access a mode and change (for example) the &lt;Contrast&gt;, you are changing the contrast for that mode only.</li> <li>&lt;Contrast&gt; : Used to adjust the contrast between the object and the background.</li> <li>&lt;Brightness&gt; : Used to adjust brightness of the entire picture.</li> <li>&lt;Sharpness&gt; : Used to adjust the sharpness of the picture.</li> <li> When the input signal is PC Timing (D-Sub/HDMI), the &lt;Sharpness&gt; cannot be adjusted.</li> <li>&lt;Color&gt; : Used to adjust color lighter or darker.</li> <li> When the input signal is PC Timing (D-Sub/HDMI), the &lt;Color&gt; cannot be adjusted.</li> <li>&lt;Tint&gt; : Used to obtain more natural color of objects using Green or Red enhancement.</li> <li> When the input signal is PC Timing (D-Sub/HDMI) or PAL and SECAM in the [S-Video] or [AV] modes, the &lt;Tint&gt; cannot be adjusted.</li> <li>&lt;Color Temperature&gt; : You can select the color temperature according to your preferences. <ul style="list-style-type: none"> <li>Factory defaults: &lt;9300K&gt;, &lt;8000K&gt;, &lt;6500K&gt;, &lt;5500K&gt;</li> <li>You can select the color temperature for the items below according to your preferences.</li> <li>&lt;R-Gain&gt;, &lt;G-Gain&gt;, &lt;B-Gain&gt; : Adjusts the color temperature of the White level.</li> <li>&lt;R-Offset&gt;, &lt;G-Offset&gt;, &lt;B-Offset&gt; : Adjusts the color temperature of the Black level.</li> <li>&lt;Color Temperature&gt;-&lt;R-Gain&gt;-&lt;G-Gain&gt;-&lt;B-Gain&gt;-&lt;R-Offset&gt;-&lt;G-Offset&gt;-&lt;B-Offset&gt;</li> </ul> </li> <li>&lt;Gamma&gt; : Changes the brightness characteristic for each color tone of an image. <ul style="list-style-type: none"> <li>The larger (+) the value, the greater the contrast of the bright and dark parts.</li> <li>The smaller (-) the value, the darker the dark parts.</li> <li>Adjustable range: -3 to +3</li> </ul> </li> <li>&lt;Save&gt; : You can save the status of a screen you adjusted according to your preferences using the &lt;Mode&gt;→&lt;User&gt; OSD.</li> <li>&lt;Reset&gt; : Restores the mode settings to the factory defaults.</li> </ul>
Size	<p>You can select a screen size according to the type of scene.</p> <p> When the input signal is PC Timing (D-Sub/HDMI), &lt;Zoom1&gt;/&lt;Zoom2&gt; is not supported.</p> <ul style="list-style-type: none"> <li>&lt;Normal&gt;-&lt;Zoom1&gt;-&lt;Zoom2&gt;-&lt;16 : 9&gt;-&lt;Custom&gt;</li> </ul>
Position	<p>Adjust the screen position if it is not aligned.</p> <p>To adjust, select the direction you want to move the screen, and then press the arrow button pointing in that direction repeatedly.</p>






MENU	DESCRIPTION
Digital NR	<p>When a dotted line is displayed or the screen shakes, you can view a better visual quality picture by enabling Noise Reduction.</p> <p>When the input signal is PC Timing (D-Sub/HDMI), &lt;Digital NR&gt; does not operate.</p>
Black Level	<p>You can select the signal black level according to the input signal. If it is unsuitable for the input signal, the dark parts may look unclear or dim.</p> <p> The &lt;Black level&gt; can only be set for the 480i and 576i RGB signals of [AV], [S-Video], and AV Timing (D-Sub) modes.</p> <ul style="list-style-type: none"> <li>For [AV], [S-Video], and the 480i and 576i signals of AV Timing (D-Sub). <ul style="list-style-type: none"> <li>&lt;0 IRE&gt; : Sets the black level to &lt;0 IRE&gt;.</li> <li>&lt;7.5 IRE&gt; : Sets the black level to &lt;7.5 IRE&gt;.</li> </ul> </li> <li>For the RGB signal of &lt;HDMI&gt; mode. <ul style="list-style-type: none"> <li>&lt;Normal&gt; : Used in a normal environment.</li> <li>&lt;Low&gt; : Used when the dark part is shown too bright.</li> </ul> </li> </ul>
Overscan	<p>Using this function, you can cut the edge of the picture when unnecessary information or images appear on the edge of the picture.</p> <p> This is not supported in [AV] and [S-Video] modes.</p> <p> This is supported only when the input signal is AV Timing (D-Sub) or AV Timing (HDMI).</p> <p> If &lt;Overscan&gt; is turned off, unnecessary extra parts at the edges of an image may be shown. In this case, turn &lt;Overscan&gt; on.</p>
Film Mode	<p>Using this function, you can set the display mode so that it is optimized for playing movies.</p> <ul style="list-style-type: none"> <li>&lt;Off&gt;-&lt;Auto&gt;</li> </ul> <p> &lt;Film Mode&gt; is only be supported for the [AV], [S-Video], 480i, and 576i of AV Timing (D-Sub) signals.</p>
PC	<p>Eliminates or reduces noise that causes unstable screen quality, such as screen shaking. If the noise is not removed using Fine Adjustment, adjust the frequency to the maximum and then perform Fine Adjustment again.</p> <p> These functions are only enabled for the PC Timing (D-Sub/HDMI) input of the D-Sub terminal.</p> <p> Refer to PC Timing (D-Sub/HDMI).</p> <ul style="list-style-type: none"> <li>&lt;Auto Adjustment&gt; : Used to adjust the frequency and phase of PC screen automatically.</li> <li>&lt;Coarse&gt; : Used to adjust the frequency when vertical lines appear on PC screen.</li> <li>&lt;Fine&gt; : Used to fine tune the PC screen.</li> <li>&lt;Reset&gt; : Using this function, you can reset the PC menu settings to the factory default settings.</li> </ul>
Zoom	<p>Enlarges the PC screen to 2X, 4X, or 8X.</p> <p> This function is only enabled when the input signal is PC Timing (D-Sub/HDMI).</p>






### 3-5-3. Setup




MENU	DESCRIPTION
Install	<p>To tailor the picture to the installation location, you can invert the projected images vertically / horizontally.</p> <ul style="list-style-type: none"> <li>• &lt;Front-Floor&gt; : Normal Image</li> <li>• &lt;Front-Ceiling&gt; : Horizontal/Vertical Reversed Image</li> <li>• &lt;Rear-Floor&gt; : Horizontally Reversed Image</li> <li>• &lt;Rear-Ceiling&gt; : Vertically Reversed Image</li> </ul>
Lamp Mode	<p>Used to set the image brightness by adjusting the amount of light generated by the lamp.</p> <ul style="list-style-type: none"> <li>• &lt;Eco&gt; : This mode is optimized for screens smaller than 100 inches. This mode decreases the lamp brightness and power consumption in order to extend the lamp lifetime and reduce noise and power consumption.</li> <li>• &lt;Normal&gt; : This mode is the most general mode and works well in most situations.</li> <li>• &lt;Bright&gt; : This mode maximizes the lamp brightness when the ambient illumination is bright. As the brightness of the lamp increases, the lamp lifetime can be reduced and noise and power consumption may increase.</li> </ul>
Auto Keystone	<p>If video scenes are distorted or tilted, you can compensate for this by setting the &lt;Auto Keystone&gt; function to &lt;On&gt; so that the &lt;V-Keystone&gt; function automatically starts.</p> <ul style="list-style-type: none"> <li>• &lt;Off&gt;-&lt;On&gt;</li> </ul>
Keystone	<p>If video scenes are distorted or tilted, you can compensate for this using the vertical/horizontal Keystone function.</p> <ul style="list-style-type: none"> <li>• &lt;V-Keystone &gt; : When the projector image is not displayed vertically on the screen, the image can be calibrated using the &lt;V-Keystone&gt; function.</li> <li>• &lt;H-Keystone&gt; : When the projector image is not displayed horizontally on the screen, the image can be calibrated using the &lt;H-Keystone&gt; function.</li> </ul> <p> The &lt;Keystone&gt;, which is a function for calibrating a skewed image, may degrade image quality when it is activated.</p> <p> The sound output of your projector is temporarily stopped while the keystone is being changed.</p> <p> The &lt;Keystone&gt; function does not adjust the appearance of the On Screen Display (OSD).</p>
Background	<p>You can set the &lt;Background&gt; the projector displays when there is no signal from the external device connected to the projector. When the projector receives a signal, the &lt;Background&gt; you set disappears and the projector displays a normal screen.</p> <ul style="list-style-type: none"> <li>• &lt;Logo&gt;-&lt;Blue&gt;-&lt;Black&gt;</li> </ul>
Test Pattern	<p>Generated by the projector itself. Use to optimize the installation of the projector.</p> <ul style="list-style-type: none"> <li>• &lt;Crosshatch&gt; : You can check whether the picture is distorted or not.</li> <li>• &lt;Screen Size&gt; : You can refer to picture format sizes such as 1.33 : 1 or 1.78 : 1.</li> </ul>



MENU	DESCRIPTION																												
Video Type	<p>If the screen quality is abnormal as a result of the projector not identifying the input signal type automatically in &lt;PC&gt; or &lt;HDMI&gt; mode, you can manually set the input signal.</p> <p> In &lt;PC&gt; mode, &lt;Video Type&gt; is only enabled if the input signal is AV Timing (D-Sub). However, for a separate H/V sync., &lt;Video Type&gt; is only enabled for the 1280 x 720p 59.94 Hz/60 Hz signals.</p> <p> In &lt;HDMI&gt; mode, &lt;Video Type&gt; is only enabled for the 640x480p 59.94Hz/60 Hz and 1280x720p 59.94Hz/60 Hz signals.</p> <ul style="list-style-type: none"><li>• &lt;Auto&gt;-&lt;RGB(PC)&gt;-&lt;RGB(AV)&gt;-&lt;YPbPr(AV)&gt; : &lt;PC&gt; mode</li><li>• &lt;Auto&gt;-&lt;PC&gt;-&lt;AV&gt; : &lt;HDMI&gt; mode</li></ul> <table><tr><th colspan="2">Usage</th><th>Color, Sharpness, Tint</th><th>PC menu and zoom</th></tr><tr><td>RGB(PC)</td><td>When connecting the RGB output of a PC to the D-Sub terminal</td><td>Disabled</td><td>Enabled</td></tr><tr><td>RGB(AV)</td><td>When connecting the RGB output of an AV device (STB, DVD, etc...) to the D-Sub terminal</td><td>Enabled</td><td>Enabled</td></tr><tr><td>YPbPr(AV)</td><td>When connecting the YPbPr output of an AV device (STB, DVD, etc...) to the D-Sub terminal</td><td>Enabled</td><td>Disabled</td></tr><tr><td>PC</td><td>When connecting a PC to the HDMI terminal</td><td>Disabled</td><td>Enabled</td></tr><tr><td>AV</td><td>When connecting an AV device (STB, DVD, etc...) to the HDMI terminal</td><td>Enabled</td><td>Disabled</td></tr><tr><td>Auto</td><td>Auto settings</td><td>—</td><td>—</td></tr></table>	Usage		Color, Sharpness, Tint	PC menu and zoom	RGB(PC)	When connecting the RGB output of a PC to the D-Sub terminal	Disabled	Enabled	RGB(AV)	When connecting the RGB output of an AV device (STB, DVD, etc...) to the D-Sub terminal	Enabled	Enabled	YPbPr(AV)	When connecting the YPbPr output of an AV device (STB, DVD, etc...) to the D-Sub terminal	Enabled	Disabled	PC	When connecting a PC to the HDMI terminal	Disabled	Enabled	AV	When connecting an AV device (STB, DVD, etc...) to the HDMI terminal	Enabled	Disabled	Auto	Auto settings	—	—
Usage		Color, Sharpness, Tint	PC menu and zoom																										
RGB(PC)	When connecting the RGB output of a PC to the D-Sub terminal	Disabled	Enabled																										
RGB(AV)	When connecting the RGB output of an AV device (STB, DVD, etc...) to the D-Sub terminal	Enabled	Enabled																										
YPbPr(AV)	When connecting the YPbPr output of an AV device (STB, DVD, etc...) to the D-Sub terminal	Enabled	Disabled																										
PC	When connecting a PC to the HDMI terminal	Disabled	Enabled																										
AV	When connecting an AV device (STB, DVD, etc...) to the HDMI terminal	Enabled	Disabled																										
Auto	Auto settings	—	—																										
Caption	<p>The &lt;Caption&gt; function is supported when the external analog signal (from either the Video or S-Video terminal) contains subtitles.</p> <p> The &lt;Caption&gt; function will not operate in &lt;PC&gt; (including components) or &lt;HDMI&gt; mode.</p> <p> Depending on the external signal, a change to the channel or &lt;Field&gt; settings may be required.</p> <p> Each &lt;Channel&gt; and &lt;Field&gt; contains different information. &lt;Field&gt;&lt;2&gt; carries additional information to supplement information contained in &lt;Field&gt;&lt;1&gt;. (e.g. If English subtitles are provided on &lt;Channel&gt;&lt;1&gt;, Spanish subtitles will be provided on &lt;Channel&gt;&lt;2&gt;.)</p> <ul style="list-style-type: none"><li>• &lt;Caption&gt; : &lt;Off&gt;-&lt;On&gt;</li><li>• &lt;Mode&gt; : &lt;Caption&gt;-&lt;Text&gt;</li><li>• &lt;Channel&gt; : &lt;1&gt;-&lt;2&gt;</li><li>• &lt;Field&gt; : &lt;1&gt;-&lt;2&gt;</li></ul>																												

MENU	DESCRIPTION
Network	<p>By connecting a LAN cable between the PC and projector, you can use the following supplementary functions.</p> <p>On your PC, you can check the projector's conditions (lifespan of the lamp, operation error, temperature) and remotely control the projector's power On/Off, brightness, and sound On/Off .</p> <ul style="list-style-type: none"> <li>• &lt;Network&gt; : &lt;On&gt; - &lt;Off&gt;</li> <li>• &lt;IP Setting&gt; <ul style="list-style-type: none"> <li>&lt;Automatic&gt; : Automatically allots the IP address, Subnet mask and Gateway.</li> <li>&lt;Manual&gt; : Allows you to manually enter the IP address, Subnet mask and Gateway manually.</li> </ul> </li> <li>• &lt;Server IP Setting&gt; : Allows you to enter the server PC's IP address.</li> </ul> <p> Remote Control : Navigate between options using ◀ / ▶ buttons. Input the values using ▲ / ▼ buttons.</p> <p> To use the network function, &lt;Network&gt; must be set to &lt;On&gt;.</p> <p> If the network connection fails, enter the IP address of the server PC under &lt;Server IP Setting&gt;.</p>
Reset	<p>Using this function, you can reset various settings to the factory default settings.</p> <ul style="list-style-type: none"> <li>• &lt;Factory Default&gt; : Changes the settings to the factory defaults.</li> <li>• &lt;Reset Filter Time&gt; : Resets the filter time.</li> </ul>

### 3-5-4. Option



MENU	DESCRIPTION
Language	You can select the language used for the menu screen.
Menu Option	<ul style="list-style-type: none"> <li>• &lt;Position&gt; : You can move Menu Position up/down/left/right.</li> <li>• &lt;Transparency&gt; : You can set the translucency of the menu. <ul style="list-style-type: none"> <li>• &lt;High&gt;-&lt;Medium&gt;-&lt;Low&gt;-&lt;Opaque&gt;</li> </ul> </li> <li>• &lt;Display Time&gt; : You can set the display time of the menu. <ul style="list-style-type: none"> <li>• &lt;5 sec&gt;-&lt;10 sec&gt;-&lt;30 sec&gt;-&lt;60 sec&gt;-&lt;90 sec&gt;-&lt;120 sec&gt;-&lt;Stay On&gt;</li> </ul> </li> </ul>
Sound	<p>Adjusts the right and left audio balance and equalizer of the 3W stereo speaker embedded in the projector.</p> <ul style="list-style-type: none"> <li>• &lt;Balance&gt;-&lt;100Hz&gt;-&lt;300Hz&gt;-&lt;1kHz&gt;-&lt;3kHz&gt;-&lt;10kHz&gt;</li> </ul>

MENU	DESCRIPTION
Filter Check Time	<p>Sets the check period for the filter. (Unit: hour)</p> <ul style="list-style-type: none"> <li>• &lt;Off&gt;-&lt;100&gt;-&lt;200&gt;-&lt;400&gt;-&lt;800&gt;</li> </ul> <p> If the filter usage time is larger than the filter check period, the filter check message is displayed for a minute whenever the projector is turned on.</p> <p> Filter check message: &lt;Check the filter, and if necessary, clean or replace it.&gt;.</p>
Auto Power On	<p>With Auto Power On, if power is supplied to the projector, it turns on automatically without your pressing the Power button.</p> <ul style="list-style-type: none"> <li>• &lt;Off&gt;-&lt;On&gt;</li> </ul>
Sleep Timer	<p>With Sleep Timer on, if there is no input signal for the specified time, the projector turns off automatically.</p> <p>(There must be no button input from the remote control or the top of the projector for the specified time)</p> <ul style="list-style-type: none"> <li>• &lt;Off&gt;-&lt;10 min&gt;-&lt;20 min&gt;-&lt;30 min&gt;</li> </ul>
Information	<p>You can check external source signals, picture setup, PC picture adjustment.</p>

### 3-6-1. Management using the Web Browser

The Web Browser lets you monitor and control one projector from a PC without installing any software. Before you can use the Web Browser, you must connect your projector to your local area network. For directions explaining how to connect to a network, see section 2-20, Connecting to a Network.

To control multiple projectors from a single PC, install and run Samsung Projector Manager.

For information about Samsung Projector Manager, go to 3-6-2.

☞ Check the network connection between the PC and projector before connecting the Web Browser. If the network connection (see section 2-20, Connecting to a Network) has failed, the Web browser window may not be available for use.


- To use the Web Browser, your PC must meet the following minimum system requirement :
  - <RAM>: More than 10MB
  - <Hard Disk> capacity: More than 10MB
  - Display resolution: More than 640 x 480
  - Supported OS : Microsoft Windows XP, Windows Vista
  - Web browser : Microsoft Internet Explorer 6 or later version, Netscape Navigator 9 or later version, Mozilla FireFox 3.0.x or later version, Google Chrome.

#### 1. Connecting

- Enter the projector's IP address into the web browser address bar.

☞ You can see the projector's IP address by pressing the Menu button and selecting Setup>Network>IP Setting.

- The Network Projector window appears. For information about control items in the Network Projector window, refer to the items under Section 3-5, Using the Screen Adjustment Menu.
- Some functions listed in 'Using the Screen Adjustment Menu' cannot be used in the web browser because of limitations in remote control by the network.



## 3-6-2. Projector Management using PC Software

You can monitor and control more than one projector using Samsung Projector Manager.

- To use Samsung Projector Manager, your PC must meet the following minimum system requirement :
  - <RAM>: More than 10MB
  - <Hard Disk> capacity: More than 10MB
  - Display resolution: More than 640 x 480
  - Supported OS : Microsoft Windows XP, Windows Vista


### 1. Installing the Samsung Projector Manager

- Click 'Samsung Projector Manager' on the CD supplied.
- Install according to the instructions displayed on the PC screen.


### 2. Running the Samsung Projector Manager

When the installation of Samsung Projector Manager and the network setup for the projector have been completed, the Samsung Projector Manager will be available for use.

- Click Start > Samsung Projector > Samsung Projector Manager




- The <Projector Remote Controller> window appears.



### 3. Using the Samsung Projector Manager

- Projector Grouping and Registering
- To browse projectors connected to the PC automatically, press Tool > Auto Search
- To group or directly register the projectors, select List>Projector, right-click over Network Projector under Projector List. and then

select Add Projector.




Projector Name	:	Projector 1
IP Address	:	192 . 168 . 0 . 100
Subnet Mask	:	255 . 255 . 255 . 0
Gateway	:	192 . 168 . 0 . 1
Group Name	:	Default Group


ADD Exit

- Specify the Projector Name, IP Address and Group Name to register and then press ADD.
  - ☑ Any group whose name is not specified will automatically be named 'Default Group.' To remove and / or rename a registered projector, right-click and then select Delete and / or Rename respectively.
  - ☑ If a projector is not displayed on the Projector List after registration, check if the network connection (see section 2-20, Connecting to a Network ) and the network settings (see 3-5-3, Setup > Network ) are properly configured.
  - ☑ To save or load the registered projector's information, select File → Export Config/Import Config.





- Projector Management
- You can check a projector's lamp condition, temperature, operation, errors, etc in real time.















**1** : You can view a projector's Name, IP Address, Group, Power On/Off status, LAMP lifespan, operation errors (represented by icons), etc in real time.

 Samsung Projector Manager displays icons that indicate a projector's status. The icons are listed in the tables below. If the icons indicate a problem with your projector,see [Clearing Indicator Problems](#) in section 3-4, [LED Indications](#).







- Warning and Error status icons

ICONS	STATUS	STATE	MEASURES
	Warning	The lens cover has not opened completely.	Refer to Action 3 in Clearing Indicator Problem.
	Error	The lamp cover protecting the lamp unit is not properly closed.	Refer to Action 2 in Clearing Indicator Problem.
	Error	The lamp is not operating normally.	Refer to Action 6 in Clearing Indicator Problem.
	Error	The lamp has reached the end of its life.	The lamp needs to be replaced.




ICONS	STATUS	STATE	MEASURES
	Error	The cooling fan 1 is not operating normally.	Refer to Action 1 in Clearing Indicator Problem.
	Error	The cooling fan 2 is not operating normally.	
	Error	The cooling fan 3 is not operating normally.	
	Error	The cooling fan 4 is not operating normally.	
	Error	The cooling fan 5 is not operating normally.	
	Error	The cooling fan 6 is not operating normally.	
	Warning	The internal temperature of the projector has risen higher than the limit.	Refer to Action 5 in Clearing Indicator Problem.
	Error	The internal temperature of the projector has risen higher than the limit.	Refer to Action 5 in Clearing Indicator Problem.
	Error	The internal temperature of the projector has risen higher than the limit.	Refer to Action 5 in Clearing Indicator Problem.
	Warning	The air filter has reached the end of its life.	The air filter needs to be replaced.
	Warning	The air filter has been blocked by dust.	The air filter needs to be cleaned.
	Error	The air filter has been blocked by dust.	The air filter needs to be cleaned.


Temperature level status icons

ICONS	STATUS	STATE	MEASURES
	Temperature status	The projector's internal temperature is normal.(standby mode)	It's normal.
	Temperature status	The projector's internal temperature is normal.(low)	It's normal.
	Temperature status	The projector's internal temperature is normal.(medium)	It's normal.
	Temperature status	The projector's internal temperature is normal.(little bit high)	It's normal.
	Temperature status	The projector's internal temperature is higher than the limit.	Refer to Action 4 in Clearing Indicator Problem.
	Temperature status	The projector's internal temperature is too high. The projector is turned off automatically.	Refer to Action 5 in Clearing Indicator Problem.


- Managing the Projectors



**1** : Using the icons in the Projector List (only applicable to 'V'-marked projectors in the monitoring window)




(Refresh): Updates the status of a projector.




(Power On): Turns on the power of a projector.



(Power Off): Turns off the power of a projector.




(Switch Source): Selects source from HDMI, S-VIDEO, AV, PC, MP.



(Blank On/Off): Turns on/ off the screen of a projector.



(Mute On/Off): Mutes on/ off the sound of a projector.



(Adjust Aspect Ratio): Adjusts the aspect ratio of a projector to either 16:9 or 4:3.

However, if products do not provide Media Play, MP source is not available.

**2** : Connecting the Web browser from Samsung Projector Manager

By connecting the Web Browser in Samsung Projector Manager, you can use more diverse functions. To perform the Web browser connection, select a Projector to connect to, and then right-click to select "Web browser."

If the Web browser connection fails, check whether the network connection (see section 2-20, Connecting to a Network ) and network settings (see 3-5-3, Setup > Network) are correctly configured.

Operating one projector using both Samsung Projector Manager and the Web browser at the same time may cause a slowdown in PC operation or an error.

- Using the Schedule function

Using the Schedule function, you can manage your projectors more efficiently.  
If you select List>Schedule, the following window appears.




The screen has four buttons:

- New : Creates a projector to make a Schedule for.
- Delete : Deletes the Schedule for a selected projector.
- Delete All : Deletes the Schedule for all of the projectors.
- Edit : Edits the Schedule for a selected projector.

- Registering a New Schedule

To register a new schedule, follow these steps:


1. Press the New button. The New Schedule screen appears.



2. Select the projectors to apply the new schedule to from the Select Projectors field. When you select a projector, a check mark appears in the check box to its left.
3. Set the new schedule Title, Repeat, Time, and Work, and enter a Description of the Schedule. Explanations for each of these terms is below.
  - Title : Sets the name of a Schedule
  - Repeat : Sets the schedule repetition (Once- Executes only once, Every - Specifies a repetition date)
  - Time : Determines the time at which a schedule will be executed
  - Work : Sets Source switch or Power On/Off
  - Description : Shows a detailed description of a Schedule
4. After you have entered all the information, press ADD.  
You can view the registration history of a Schedule. You can also view the status of a Schedule. The Status codes are below:
  - Complete: Schedule complete.

- Running: Repetitive schedule is running.

- To save or load the registered schedule, select File → Export Config/Import Config.
- If you want to operate a Schedule loaded by Import Config, load projector's information in advance.



- Other settings

The Tools selection in the Menu Bar contains two menu items, Configure monitor items and Option.

- Configure monitor items

Configure monitor items lets you select an item to be displayed in the monitoring window display. After you select the item, you set the display priority of the item by moving it up or down in the list of item you have selected for display.

- Options

**Automatically Run**– When a PC is turned on, Samsung Projector Manager will be turned on automatically.


Minimize to system tray – Samsung Projector Manager will be minimized to system tray.

File contains two selections.

- File> Export Config : Saves all of the configured settings under Samsung Projector Manager in the desired file names to the corresponding folders.
- File> Import Config : Imports a saved Configuration file. Sets the Samsung Projector Manager to the saved settings.

## 4 Troubleshooting

### 4-1 Before Requesting Service

 Please check the following before requesting After-Sales service. If the problem continues, please contact your nearest Samsung Electronics Service Center.

	Symptoms	Troubleshooting
Installation and Connection	No Power.	Check the power cable connections.
	I want to install my projector on the ceiling.	The ceiling installation support is sold separately. Contact your local product distributor.
	Can't select an External Source.	Be sure that the video connection cable or cables are properly-connected to the proper port. If the device is not connected properly, it can not be selected.
Menu and Remote Control	Remote control does not work.	<p>Be sure that the proper external source is selected.</p> <p>Check the battery in the remote. If there is something wrong with it, replace it with a new battery of the recommended size.</p> <p>Be sure to aim the remote at sensor on the back of the unit and at a distance of no more than approximately 23 feet(7 m).</p> <p>Remove any obstacles between your remote control and the product.</p> <p>Direct light from 3-way light bulbs or other lighting devices on the remote sensor of the projector may affect its sensitivity and cause the remote control to malfunction.</p> <p>Check if the remote control battery compartment is empty.</p> <p>Check whether the LED indicator on the top of the projector is turned on.</p>
	I cannot select a menu.	Check if the menu is displayed in gray. A gray-colored menu is unavailable.


	Symptoms	Troubleshooting
Screen and External Source	Cannot see picture images.	<p>Be sure that the power cord of the projector is connected.</p> <p>Be sure that the proper input source is selected.</p> <p>Check that the connectors are properly connected to the ports at the back of the projector.</p> <p>Check the Remote Control batteries.</p> <p>Be sure that the &lt;Color&gt; and&lt;Brightness&gt; settings are not at their lower limit.</p>
	Poor color.	Adjust the <Tint> and <Contrast>.
	Images are not clear.	<p>Adjust the focus.</p> <p>Check if the projector is too far from or too near to the screen.</p>
	Strange noise.	If a strange sound continues, contact our service center.
	The operating LED is lit up.	Refer to Corrective Actions According to LED Indications(3-4).
	Lines appear on screen.	On screen noise may occur when using your PC. Adjust the frequency (refresh rate) of the screen.
	No external device screen is displayed.	Check the operating status for the external device and check whether the adjustment items, such as the <Brightness> and the <Contrast> have been changed correctly in the <Mode> command screen of the Projector menu.
	Only a blue screen appears.	Be sure to connect the external devices properly. Check the connection cables again.
	Screen appears in black and white or odd color or screen is too dark or bright.	<p>As mentioned above, check the adjustment items such as &lt;Brightness&gt;, &lt;Contrast&gt;, or &lt;Color&gt; in the menu.</p> <p>If you want to restore various settings to their factory defaults, run &lt;Factory Default&gt;from the menu.</p>

	Symptoms	Troubleshooting
<b>Network</b>	The Web browser will not start up.	Check the system requirements for the PC to connect to the Web browser.
	The Web browser will not connect to the projector.	<ol style="list-style-type: none"> <li>1. Check whether the power cable is connected to the projector (See Section 2-11, Connecting the Power)</li> <li>2. Check if the network environments for the PC and projector are correct (See Section 2-20, Connecting to a Network )</li> <li>3. Check whether the correct network card to be used for the PC has been selected when the PC (server) has more than two network cards.</li> </ol>
	Installation of Samsung Projector Manager has failed.	Check Samsung Projector Manager's system requirements for PCs.
	The projector will not connect to Samsung Projector Manager.	<ol style="list-style-type: none"> <li>1. Check if the &lt;IP Setting&gt; and network connection between the PC and projector are correct.</li> <li>2. If &lt;IP Setting&gt; for the projector is set to &lt;Automatic&gt;, check whether the PC and projector share the same network. If it is not the same network, configure the IP of the server PC using the &lt;Server IP Setting&gt; option.</li> <li>3. Check if the projector access is blocked by the PC's Windows firewall.</li> <li>4. If Samsung Projector Manager connection's failure persists, remove and retry installation.</li> </ol>
	I want to remove Samsung Projector Manager.	<p>Samsung Projector Manager can be removed using the [Add or Remove Programs] option. To remove Samsung Projector Manager,</p> <p>follow these steps :</p> <ol style="list-style-type: none"> <li>1. Select [Control Panel] from the [Start] menu. (Windows XP)</li> <li>2. Run [Add or Remove Programs]</li> <li>3. Select Samsung Projector Manager under [Add or Remove Programs] and click [Change/Remove].</li> <li>4. Select "Yes" to start the removal.</li> <li>5. Follow additional directions as they appear on your screen.</li> </ol>

## 5 More Information

### 5-1 Specifications

MODEL		SP-L301	SP-L331	SP-L351
Panel	Size	0.63" 3P LCD	0.63" 3P LCD with MLA	
	Resolution	XGA (1024 x 768)		
Aspect ratio		4:3		
Power	Power Consumption	290 W (Standby : under 1W)		
	Voltage	100~240V AC, 50/60Hz		
Lamp	Power Consumption	220W (Normal : 200W, Eco : 152W)		
	Life Time	2,000 Hours (Eco : 2,500 Hours)		
Dimension		291 x 289 x 127 mm / 11.5 x 11.4 x 5 inches		
Weight		3.8 Kg / 8.4 lbs		
Key Features	Brightness	3,000 ANSI	3,300 ANSI	3,500 ANSI
	Contrast	500 :1	400 :1	400 :1
	Screen Size (Diagonal)	Diagonal 40 inches ~ 300 inches		
	Projection Range	1 m ~ 10 m / 39.4 inches ~ 393.7 inches		
	Keystone	Auto : Vertical(±30°) / Manual: Vertical (±30°), Horizontal (±30°)		
	Network	RJ 45		
	Zoom Adjustment	Manual		
	Focus Adjustment	Manual		
	Lens	F=1.65~1.93, f=18.5mm~22.5mm		
	Zoom Ratio	1:1.2		
Input signal	D-Sub 15p	Analog RGB, analog YPbPr		
	HDMI	Digital RGB, digital YCbCr		
	Mini DIN x 1	S-Video		
	RCA x 1	Composite video		
Speaker		3W x 2 (Stereo)		
User Environ- ment	Temperature and Humidity	Operating : Temperature 41 °F ~ 95 °F (5 °C ~ 35 °C),Humidity 20 % ~ 80 % (Non-condensing)		
		Storage : Temperature -14 °F~140 °F (-10 °C ~ 60 °C),Humidity 10 % ~ 90 % (Non-condensing)		
Noise		Eco : 30dB, Normal : 32dB, Bright : 35dB		

 This Class B equipment is designed for home and office use. The equipment has been registered regarding EMI for residential use. It may be used in all areas. Class A is for office use. Class A is for business while class B emits less electromagnetic waves than class A.



- The LCD panel used in the LCD projector consists of hundreds of thousands of fine pixels. Like other video display devices, the LCD panel may contain bad pixels which do not operate. When shipping a product, the conditions for identifying bad pixels and the number of bad pixels that a LCD panel is allowed to contain are strictly managed in accordance with the relevant specified standards by the LCD panel manufacturer and our company. Though a screen may have some dead pixels, this does not affect the overall screen quality and the lifetime of the product.

### Communication Format (Complies with the RS232C Standard)

- Baud rate : 9,600 bps
- parity : None
- Data bits : 8, stop bit : 1
- Flow Control : None

### Serial Communication Protocol

#### 1. Command Packet Structure [7bytes]

0x08	0x22	cmd1	cmd2	cmd3	value	CS
------	------	------	------	------	-------	----

- A command packet consists of 7 bytes in total.
  - The two bytes 0x08 and 0x22 signify that the packet is for serial communication.
  - The following 4 bytes represent a pre-defined command that can be defined by the user.
  - The last byte is the checksum which checks the validity of the current packet.
- 
- Header [2 Byte]: Pre-defined values fixed to 0x08 and 0x22.
  - Cmd1 [1 Byte]: The first value of the code defined in the command list (Hexadecimal)
  - Cmd2 [1 Byte]: The second value of the code defined in the command list (Hexadecimal)
  - Cmd3 [1 Byte]: The third value of the code defined in the command list (Hexadecimal)
  - Value [1 Byte]: Input parameter for the command (Default: 0) (Decimal)
  - CS [1 Byte]: Checksum (the 2's complement of the sum of all the values except for the CS value.)

#### 2. Response Packet Structure [3 Bytes]

##### 1. Success

0x03	0x0C	0xF1
------	------	------

##### 2. Fail

0x03	0x0C	0xFF
------	------	------

- When the received packet from an external device has a valid value, a Success packet is sent. Otherwise, a Fail packet is sent.
- A Fail packet is sent if:
  - The received packet length is not equal to 7 bytes.
  - The 2 byte packet header value is not equal to 0x08, 0x22.
  - The check sum is incorrect.
    - Failure detection by an external device
- An external device classifies the packet as Fail if it does not receive a Success packet within 100ms.

## Command Table

CONTROL ITEM				CMD1	CMD2	CMD3	VALUE
General	Power	Power	Display OSD / Power On	0x00	0x00	0x00	0
			OK				1
			Cancel				2
			Direct Power Off				3
	Volume	Direct		0x01	0x00	0x00	(0~100)
		Continuous	Up			0x01	0
			Down			0x02	0
	Mute		On	0x02	0x00	0x00	0
			Off				1
	Blank		On	0x03	0x00	0x00	0
			Off				1
	Still		On	0x04	0x00	0x00	0
			Off				1
Input	Source List	AV	AV	0x0A	0x00	0x01	0
		S-Video	S-Video			0x02	0
		PC	PC			0x03	0
		HDMI	HDMI			0x04	0

CONTROL ITEM				CMD1	CMD2	CMD3	VALUE	
Picture	Mode	Standard		0x0B	0X00	0x00	0	
		Presentation					1	
		Text					2	
		Movie					3	
		Game					4	
		User					5	
	Contrast	0~100				0X02	0x00	(0~100)
	Brightness	0~100				0X03	0x00	(0~100)
	Sharpness	0~100				0X04	0x00	(0~100)
	Color	0~100				0X05	0x00	(0~100)
	Tint (G/R)	G50 / R50				0x06	0x00	(0~100)
	Color Tem- perature	9300K			0x0A	0x00	1	
		8000K					2	
		6500K					3	
		5500K					4	
	WB	R offset			0x0B	0x00	(0~100)	
		G offset					0x01	(0~100)
		B offset					0x02	(0~100)
		R gain					0x03	(0~100)
		G gain					0x04	(0~100)
		B gain					0x05	(0~100)

CONTROL ITEM				CMD1	CMD2	CMD3	VALUE
Picture	Gamma	-3~3		0x0B	0x0C	0x00	(0~6)
	Save	Display OSD			0x0D	0x00	0
		OK					1
		Cancel					2
		Direct Save					3
	Reset				0x0E	0x00	0
	Size	Normal			0x0F	0x00	0
		Zoom1					1
		Zoom2					2
		16:9					3
		Custom					4
	Custom	Top	Decrease			0x01	0
			Increase				1
		Bottom	Decrease			0x02	0
			Increase				1
		Left	Decrease			0x03	0
			Increase				1
		Right	Decrease			0x04	0
			Increase				1
	Digital NR	Off			0x10	0x00	0
		On					1
	Black Level	0 IRE/NOR-MAL			0x11	0x00	0
		7.5 IRE/LOW					1
	Overscan	Off			0x12	0x00	0
		On					1
	Film Mode	Off			0x13	0x00	0
		On					1
	PC	Auto adjustment			0x14	0x00	0
		Coarse	UP		0x15	0x00	0
			DOWN				1
		fine	Up		0x16	0x00	0
			DOWN				1
		Reset	Display OSD		0x17	0x00	0
			OK				1
			Cancel				2
			Direct Reset				3

CONTROL ITEM				CMD1	CMD2	CMD3	VALUE
Picture	Zoom	x1		0x0B	0x18	0x00	0
		x2					1
		x4					2
		x8					3
		LEFT			0x19	0x00	0
		RIGHT					1
		Up					2
		Down					3
	Horizontal Position	Continuous	LEFT	0x0B	0x1A	0x00	0
			RIGHT				1
	Vertical Position	Continuous	DOWN		0x1B	0x00	0
			Up				1

CONTROL ITEM				CMD1	CMD2	CMD3	VALUE
Setup	install	F-F		0x0C	0x00	0x00	0
		F-C					1
		R-F					2
		R-C					3
	Lamp Mode	ECO			0x01	0x00	0
		Normal					1
		Bright					2
	Keystone	V-Keystone	-50~50		0x02	0x00	(0~100)
		H-Keystone	-50~50			0x01	(0~100)
		Auto Keystone	Off			0x02	0
			On				1
	Background	Logo			0x03	0x00	0
		Blue					1
		Black					2
	Test Pattern	Crosshatch			0x04	0x00	0
		Screen size					1
		Pattern Off					2
	Video Type	Auto			0x05	0x00	0
		RGB(PC)					1
		RGB(AV)					2
		YCbCr(AV)					3
		PC					4
		AV					5
	Reset	Factory Default	Display OSD		0x06	0x00	0
			OK				1
			Cancel				2
			Direct Factory Reset				3
		Reset Filter Time	Display OSD			0x01	0
			OK				1
			Cancel				2
			Direct Reset Filter Time				3
	Caption	Caption	Off		0x07	0x00	0
			On				1
		Mode	Caption			0x01	0
			Text				1
		Channel	1			0x02	0
			2				1
		Field	1			0x03	0
			2				1

CONTROL ITEM				CMD1	CMD2	CMD3	VALUE
Setup	Network	Network	Off	0x0E	0x01	0x00	0
			On				1
		IP Setting	Automatic		0x02	0x00	0
			Manual				1
			IP Address		0x03	0x00	0~255
						0x01	0~255
						0x02	0~255
						0x03	0~255
			Subnet Mask		0x04	0x00	0~255
						0x01	0~255
						0x02	0~255
						0x03	0~255
			Gateway		0x05	0x00	0~255
						0x01	0~255
						0x02	0~255
						0x03	0~255
		Server IP Setting	Server IP		0x06	0x00	0~255
						0x01	0~255
						0x02	0~255
						0x03	0~255



CONTROL ITEM				CMD1	CMD2	CMD3	VALUE
Option	Language	English		0x0D	0x00	0x00	0
		Deutsch					1
		Nederlands					2
		Español					3
		Français					4
		Italiano					5
		Svenska					6
		Português					7
		Русский					8
		中国語					9
		한국어					10
		Türkçe					11
		ไทย					12
	Menu Option	Position	LEFT	0x0D	0x01	0x00	0
			RIGHT				1
			UP				2
			DOWN				3
		Transpar- ency	High		0x02	0x00	0
			Medium				1
			Low				2
			Opaque				3
		Display Time	5 sec		0x03	0x00	0
			10 sec				1
			30 sec				2
			60 sec				3
			90 sec				4
			120 sec				5
			Stay On				6

CONTROL ITEM				CMD1	CMD2	CMD3	VALUE
Option	SOUND	Balance	Up	0x0D	0x04	0x00	0
			Down				1
		100Hz	Up			0x01	0
			Down				1
		300Hz	Up			0x02	0
			Down				1
		1KHz	Up			0x03	0
			Down				1
		3KHz	Up			0x04	0
			Down				1
		10KHz	Up			0x05	0
			Down				1
	Filter Check Time	off			0x05	0x00	0
		100					1
		200					2
		400					3
		800					4
	Auto Power ON	OFF			0x06	0x00	0
		ON					1
	Sleep Timer	OFF			0x07	0x00	0
		10 min					1
		20 min					2
		30 min					3
	Information				0x08	0x00	0

## 5-3 Contact SAMSUNG WORLDWIDE

-  • If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

NORTH AMERICA		
U.S.A	1-800-SAMSUNG(726-7864)	<a href="http://www.samsung.com/us">http://www.samsung.com/us</a>
CANADA	1-800-SAMSUNG(726-7864)	<a href="http://www.samsung.com/ca">http://www.samsung.com/ca</a>
MEXICO	01-800-SAMSUNG(726-7864)	<a href="http://www.samsung.com/mx">http://www.samsung.com/mx</a>
LATIN AMERICA		
ARGENTINA	0800-333-3733	<a href="http://www.samsung.com/ar">http://www.samsung.com/ar</a>
BRAZIL	0800-124-421 4004-0000	<a href="http://www.samsung.com/br">http://www.samsung.com/br</a>
CHILE	800-SAMSUNG(726-7864)	<a href="http://www.samsung.com/cl">http://www.samsung.com/cl</a>
COLOMBIA	01-8000112112	<a href="http://www.samsung.com/co">http://www.samsung.com/co</a>
COSTA RICA	0-800-507-7267	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
ECUADOR	1-800-10-7267	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
EL SALVADOR	800-6225	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
GUATEMALA	1-800-299-0013	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
HONDURAS	800-7919267	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
JAMAICA	1-800-234-7267	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
NICARAGUA	00-1800-5077267	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
PANAMA	800-7267	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
PUERTO RICO	1-800-682-3180	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
REP. DOMINICA	1-800-751-2676	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
TRINIDAD & TOBAGO	1-800-SAMSUNG(726-7864)	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
VENEZUELA	0-800-100-5303	<a href="http://www.samsung.com/latin">http://www.samsung.com/latin</a>
EUROPE		
AUSTRIA	0810 - SAMSUNG(7267864,€ 0.07/min)	<a href="http://www.samsung.com/at">http://www.samsung.com/at</a>
BELGIUM	02 201 2418	<a href="http://www.samsung.com/be">http://www.samsung.com/be</a> (Dutch) <a href="http://www.samsung.com/be_fr">http://www.samsung.com/be_fr</a> (French)
CZECH REPUBLIC	800 - SAMSUNG (800-726786)	<a href="http://www.samsung.com/cz">http://www.samsung.com/cz</a>
	Distributor pro Českou republiku: Samsung Zrt., česká organizační složka, Oasis Florenc, Sokolovská394/17, 180 00, Praha 8	
DENMARK	8 - SAMSUNG (7267864)	<a href="http://www.samsung.com/dk">http://www.samsung.com/dk</a>
EIRE	0818 717 100	<a href="http://www.samsung.com/ie">http://www.samsung.com/ie</a>
FINLAND	30 - 6227 515	<a href="http://www.samsung.com/fi">http://www.samsung.com/fi</a>
FRANCE	01 4863 0000	<a href="http://www.samsung.com/fr">http://www.samsung.com/fr</a>

EUROPE		
GERMANY	01805 - SAMSUNG (7267864, € 0.14/Min)	<a href="http://www.samsung.de">http://www.samsung.de</a>
HUNGARY	06-80-SAMSUNG(726-7864)	<a href="http://www.samsung.com/hu">http://www.samsung.com/hu</a>
ITALIA	800-SAMSUNG(726-7864)	<a href="http://www.samsung.com/it">http://www.samsung.com/it</a>
LUXEMBURG	02 261 03 710	<a href="http://www.samsung.com/lu">http://www.samsung.com/lu</a>
NETHERLANDS	0900 - SAMSUNG (0900-7267864) (€ 0,10/Min)	<a href="http://www.samsung.com/nl">http://www.samsung.com/nl</a>
NORWAY	3 - SAMSUNG (7267864)	<a href="http://www.samsung.com/no">http://www.samsung.com/no</a>
POLAND	0 801 1SAMSUNG (172678) 022 - 607 - 93 - 33	<a href="http://www.samsung.com/pl">http://www.samsung.com/pl</a>
PORTUGAL	808 20 - SAMSUNG (7267864)	<a href="http://www.samsung.com/pt">http://www.samsung.com/pt</a>
SLOVAKIA	0800-SAMSUNG(726-7864)	<a href="http://www.samsung.com/sk">http://www.samsung.com/sk</a>
SPAIN	902 - 1 - SAMSUNG (902 172 678)	<a href="http://www.samsung.com/es">http://www.samsung.com/es</a>
SWEDEN	0771 726 7864 (SAMSUNG)	<a href="http://www.samsung.com/se">http://www.samsung.com/se</a>
SWITZERLAND	0848-SAMSUNG(7267864, CHF 0.08/min)	<a href="http://www.samsung.com/ch">http://www.samsung.com/ch</a>
U.K	0845 SAMSUNG (7267864)	<a href="http://www.samsung.com/uk">http://www.samsung.com/uk</a>
CIS		
BELARUS	810-800-500-55-500	
ESTONIA	800-7267	<a href="http://www.samsung.com/ee">http://www.samsung.com/ee</a>
LATVIA	8000-7267	<a href="http://www.samsung.com/lv">http://www.samsung.com/lv</a>
LITHUANIA	8-800-77777	<a href="http://www.samsung.com/lt">http://www.samsung.com/lt</a>
MOLDOVA	00-800-500-55-500	
KAZAKHSTAN	8-10-800-500-55-500	<a href="http://www.samsung.com/kz_ru">http://www.samsung.com/kz_ru</a>
KYRGYZSTAN	00-800-500-55-500	
RUSSIA	8-800-555-55-55	<a href="http://www.samsung.ru">http://www.samsung.ru</a>
TADJIKISTAN	8-10-800-500-55-500	
UKRAINE	8-800-502-0000	<a href="http://www.samsung.com/ua">http://www.samsung.com/ua</a> <a href="http://www.samsung.com/ua_ru">http://www.samsung.com/ua_ru</a>
UZBEKISTAN	8-10-800-500-55-500	<a href="http://www.samsung.com/kz_ru">http://www.samsung.com/kz_ru</a>
ASIA PACIFIC		
AUSTRALIA	1300 362 603	<a href="http://www.samsung.com/au">http://www.samsung.com/au</a>
CHINA	400-810-5858 010-6475 1880	<a href="http://www.samsung.com/cn">http://www.samsung.com/cn</a>
HONG KONG	3698 - 4698	<a href="http://www.samsung.com/hk">http://www.samsung.com/hk</a> <a href="http://www.samsung.com/hk_en/">http://www.samsung.com/hk_en/</a>
INDIA	3030 8282 1-800-3000-8282 1800 110011	<a href="http://www.samsung.com/in">http://www.samsung.com/in</a>

ASIA PACIFIC		
INDONESIA	0800-112-8888	<a href="http://www.samsung.com/id">http://www.samsung.com/id</a>
JAPAN	0120-327-527	<a href="http://www.samsung.com/jp">http://www.samsung.com/jp</a>
MALAYSIA	1800-88-9999	<a href="http://www.samsung.com/my">http://www.samsung.com/my</a>
NEW ZEALAND	0800 SAMSUNG (0800 726 786)	<a href="http://www.samsung.com/nz">http://www.samsung.com/nz</a>
PHILIPPINES	1-800-10-SAMSUNG(726-7864) 1-800-3-SAMSUNG(726-7864) 1-800-8-SAMSUNG(726-7864) 02-5805777	<a href="http://www.samsung.com/ph">http://www.samsung.com/ph</a>
SINGAPORE	1800-SAMSUNG(726-7864)	<a href="http://www.samsung.com/sg">http://www.samsung.com/sg</a>
THAILAND	1800-29-3232, 02-689-3232	<a href="http://www.samsung.com/th">http://www.samsung.com/th</a>
TAIWAN	0800-329-999	<a href="http://www.samsung.com/tw">http://www.samsung.com/tw</a>
VIETNAM	1 800 588 889	<a href="http://www.samsung.com/vn">http://www.samsung.com/vn</a>
MIDDLE EAST & AFRICA		
SOUTH AFRICA	0860-SAMSUNG(726-7864)	<a href="http://www.samsung.com/za">http://www.samsung.com/za</a>
TURKEY	444 77 11	<a href="http://www.samsung.com/tr">http://www.samsung.com/tr</a>
U.A.E	800-SAMSUNG(726-7864) 8000-4726	<a href="http://www.samsung.com/ae">http://www.samsung.com/ae</a>

### Correct Disposal of This Product (Waste Electrical & Electronic Equipment) - Europe only



**(Applicable in the European Union and other European countries with separate collection systems)**

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

### Correct disposal of batteries in this product - Europe only



**(Applicable in the European Union and other European countries with separate battery return systems.)**

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.